

Cookshack, Inc.
2301 N. Ash St.
Ponca City, OK
74601



Contact us at:
1.800.423.0698 or
order online at
www.cookshack.com



Series 100 Smokehood Assembly Instructions

Use your Cookshack indoors with the Smokehood designed specifically for your Cookshack smoker. It attaches easily to the top of your smoker and removes smoke via a grease filter and fan.



Front View



Back View

Items Included:

Smokehood
36" x 5/8 drain pipe
Mounting hardware (drain
pipe clamps, self-tapping
screws)
Filter

Tools Needed:

Phillips Screwdriver
Drill

To attach:

1. Position Smokehood on top of the smoker lining up front edges. Center the hood horizontally. Drill holes in the smoker to attach the Smokehood.
2. Fasten the Smokehood using the self-tapping screws into the drilled holes.
3. On the left side of smoker, drill holes to attach drain pipe vertically 4" from the back. Fasten drain pipe using self-tapping screws and drain pipe clamps. Allow pipe to hang 1" below bottom of smoker.
4. Place the two hoses from the Smokehood and fan in the top of the drain pipe.
5. Attach fan discharge to an external vent using a standard 4" vent pipe.
6. Place a small container on the floor to catch condensation.

