

Cookshack, Inc.  
2301 N. Ash St.  
Ponca City, OK  
74601



Contact us at:  
1.800.423.0698 or  
order online at  
[www.cookshack.com](http://www.cookshack.com)



# Series 300 Smokehood

## Assembly Instructions

Use your Cookshack indoors with the Smokehood designed specifically for your Cookshack smoker. It attaches easily to the top of your smoker and removes smoke via a grease filter and fan.



Front View



Back View

### Items Included:

Smokehood  
58" x 5/8 drain pipe  
Mounting hardware (drain pipe clamps, 10 /32 x 3/4 bolt, self-tapping screws)  
Filter

### Tools Needed:

Phillips Screwdriver  
Drill  
5/16" nut driver

### To attach:

1. Position Smokehood on top of the smoker lining up front edges. Center the hood horizontally. Drill holes in the smoker to attach the Smokehood.
2. Fasten the Smokehood using the self-tapping screws into the drilled holes.
3. On the back of the smoker, drill holes and attach drain pipe vertically, 20" from left side of oven. Fasten drain pipe using the self-tapping screws and drain pipe clamps. Allow pipe to hang 1" below bottom of oven.
4. Place the two hoses from the Smokehood and fan into the top of the drain pipe.
5. Attach fan discharge to external vent using a standard 4" vent pipe.
6. Place a small container on the floor to catch condensation.

