



# TeeterLink<sup>®</sup> Tracker

## Owner's Manual





To review and register your 1-Year Warranty, go to **teeter.com/Support/Warranty-Registration**



Questions or concerns? Contact Teeter Customer Service at **800.847.0143**, or via online forms or Live Chat at **teeter.com**.

## **WARNING**

- **DO NOT** operate Tracker in wet or moist conditions.
- **DO NOT** expose Tracker to excessive heat, dust, or vibration
- **DO NOT** disassemble or replace any parts, except batteries.
- **ALWAYS** store Tracker in dry conditions at room temperature.
- **ALWAYS** store Tracker away from children and pets.
- **ALWAYS** use AAA 1.5V Alkaline batteries with Tracker.
- **ALWAYS** replace both batteries at the same time.
- **DO NOT** mix old and new batteries or different types.
- **ALWAYS** wipe the battery and device contacts clean with a dry cloth prior to battery installation.
- **ALWAYS** ensure batteries are installed correctly regarding polarity.
- **ALWAYS** remove batteries from Tracker if it is not to be used for an extended period.
- **ALWAYS** remove depleted batteries promptly.

### Included



- TeeterLink<sup>®</sup> Tracker
- 2 x AAA Batteries
- Owner's Manual
- Mounting Bracket (X & LX Series Only)

### Technical Specifications

- **Compatibility:** iOS<sup>®</sup> and Android<sup>®</sup>
- **Transmission Range:** 32 ft (30 m)
- **Sensor:** 6 Axle Motion Sensor
- **Battery Model:** 2 x AAA 1.5V Alkaline
- **Weight:** 0.15 lbs (0.07 kg)
- **Dimensions:** 3.25 x 2.75 x 1.25 in  
(8.26 x 7.00 x 3.18 cm)


# Battery Installation

- 1 Remove the Battery Lid by pressing down on the Lid Tab and pulling outward (Figure 1).
- 2 Insert the batteries noting (+) and (-).
- 3 Reattach the Battery Lid by aligning the bottom first, then snapping it into place (Figure 2).



The TeeterLink<sup>®</sup> Tracker attaches to your Teeter with a built-in magnet. **Note:** For X and LX Series Inversion Tables, skip to Page 5.

FIGURE 3



Place the Tracker on the **Main Shaft Housing**.

**NOTE:** If proper placement is not followed, the device may not work properly or may be damaged by the operation of the equipment.

Position the Tracker as shown.


Proceed to page 7.

FIGURE 4



## X & LX Series Attachment

FIGURE 5



Locate the Tracker Mount and peel off the backing.

On back of the Table Bed, locate the Upper Rib and press the Tracker Mount into place as shown.

FIGURE 6





FIGURE 7



Position the Tracker in the Upper Rib as shown.

FIGURE 8



To remove the Tracker, push an Allen Wrench through the hole in the front of the Table Bed to push the Tracker out of the Upper Rib.

## Getting Started with TeeterLink®

Download TeeterLink®

Go to: [bit.ly/teeterlink-app](https://bit.ly/teeterlink-app)



Download on the  
App Store



ANDROID APP ON


Google play

Or scan here to download:





## Pair Tracker to TeeterLink®

- 1 Enable Bluetooth® on your device.
- 2 Launch TeeterLink®.
- 3 Tap the Teeter Logo at the bottom of the screen.
- 4 With the Tracker attached to your inversion table, activate it by double tapping it.
- 5 At the top of the screen, tap **CONNECT**. The Bluetooth® Icon  will pulse and the button will show **CONNECTED** when the Tracker has paired to your device.
- 6 The Tracker will automatically power off after 30 minutes of inactivity. Double tap the Tracker to wake it up before your next session.

## Troubleshooting

- The Tracker must be within 32 ft (10 m) of your device to connect.
- Make sure Bluetooth® is enabled on your device.
- Remove and replace the Tracker batteries.
- Relaunch TeeterLink® and retry connecting.

### **Need assistance?**

Contact Teeter Product Specialists here:

Toll Free: **800-847-0143**  
teeter.com | info@teeter.com

Feel Better. Move Better.  
Live Better.

“ I created Teeter so people could  
live healthier, more active lives. ”

*-Roger Teeter*



Roger Teeter  
Founder &  
Innovator



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that the interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that of the receiver.
- Consult the dealer or an experienced radio/TV technician for help.

©2018 Teeter, Bonney Lake, WA. All rights reserved. TeeterLink, Teeter, and Teeter logo are trademarks or registered trademarks of Teeter. International law prohibits any copying. Google Play and the Google Play logo are trademarks of Google LLC. The Android robot is reproduced or modified from work created and shared by Google and used according to terms described in the Creative Commons 3.0 Attribution License. Apple and the Apple logo are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc., registered in the U.S. and other countries. IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license. The Bluetooth logo and word mark are owned by Bluetooth SIG, Inc. AF1030 0318-1

